
NOTES: (CONTINUED FROM SHEET 1)

- 6. FREEZE PROTECTION VALVE INSTALLATION INSTRUCTIONS:
 - A INSTALL VALVE SUB-ASSEMBLY ONTO MALE SECTION OF UNION AND TIGHTEN WATER-TIGHT.
 - FORM HEAT TRACE CABLE AROUND VALVE AND PLUG, AS SHOWN, ENSURING THAT HEAT TRACE CABLE IS PRESSED FIRMLY AGAINST SIDES OF VALVE (PUSH ANY LOOSE HEAT TRACE CABLE BACK INSIDE JACKET THROUGH RUBBER GROMMET).
 - SLIDE INSULATION TUBE OVER FREEZE VALVE AND UNION, UP AGAINST JACKET SURFACE. APPLY 2X CABLE TIES, AS SHOWN, TO SECURE INSULATION TUBE. TRIM EXCESS CABLE TIE STRAPPING.



SP158B VALVE SHOWN CONNECTED TO BOTTOM UNION FOR REFERENCE ONLY. VALVE CAN BE INSTALLED AT TOP OR BOTTOM.

C) Haws
Since 1906

HAWS AG
BACHWEG 3
3400 BURGDORF SWITZERLAND
T +41 (0)34 420 60 00
E-MAIL: INFO@HAWS.CH
WERSITE: WWW HAWS CH

NE REV. ECN: BY: DON B

^{-(S)} 8317CTFP AXION (10004782) 8317CTFP AXION ATEX (10004784) PART NUMBER
02081781.D
REVISION
1